

# PETRO WORKS PRODUCTS

## Starter Relay Kit Installation

Tools Required:

- 10mm Socket

**WARNING - Always disconnect the negative terminal then the positive terminal on the battery when performing any electrical work on your vehicle.**

Steps:

1. Disconnect the negative terminal, then the positive terminal on the battery.
2. Mount the relay on the firewall in the spot shown in the sample image. Loop the black wire back around and attach it to the same spot as the relay.
3. Unplug the small wire from the front of the starter. Plug the relay's WHITE wire into this front plug you just removed from the starter.
4. Plug the BLUE Wire into the front of the starter.
5. Connect the RED wire to the positive battery terminal.
6. Reconnect the positive and negative terminal to the battery.

