


DIAGNOSTIC TROUBLE CODE TABLE

EXAMPLE: When throttle position sensor is defective (Code No. 21)



DIAGNOSTIC TROUBLE CODE NO.	MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) FLASHING PATTERN	DIAGNOSTIC ITEM	DIAGNOSIS	
13		Heated oxygen sensor	Diagnose trouble according to "DIAGNOSTIC FLOW CHART" corresponding to each code No.	
14		Engine coolant temperature sensor		
15				
21		Throttle position sensor		
22				
23		Intake air temperature sensor		
25				
24		Vehicle speed sensor		
33		Mass air flow sensor		
34				
41		Ignition fail-safe signal		
42		Camshaft position sensor		
44		Idle switch of throttle position sensor		
45				
51		EGR system (For 1994 model U.S.A. spec. and 1995 model vehicle only)		
52		Fuel system (For 1994 model U.S.A. spec. and 1995 model vehicle only)		
53		Spec. of ECM (For 1994 model U.S.A. spec. and 1995 model vehicle only)		ECM of different spec. (ECM for different spec. vehicle is installed to 1994 model U.S.A. spec. or 1995 model vehicle)
ON		ECM		ECM failure.
12		Normal	This code appears when none of the other codes (above codes) are identified.	